

Guying packs - tips and instructions

The guying pack contains material suitable for guying telescopic masts in 3 directions. Please refer to the packaging for the specific type of mast for which it is intended. Overview of the individual kits:

ID	For Mast	Guying Levels	Rope clips	Tensioners	Links	Rope ft.
			ID ADC03	ID CL276	ID ACC06	M-P 3+
PGPT25S	25 ft.	2	12	6	6	165
PGPT34S	34 ft.	3	18	9	9	330
PGPT50S	50 ft.	4	24	12	12	660
PGPT25H	25 ft. Heavy	2	12	6	6	165
PGPT34H	34 ft. Heavy	3	18	9	9	330

Recommended distances, individual rope lengths (with a margin of about 2 ft. on each anchor), and segment numbers for placement of guy rings:

Mast	Dist. [ft.]	Rope length [ft.]				Guy rings on mast segments in order from the bottom:
		Lev. top	Lev. -1	Lev. -2	Lev. -3	
25 ft.	20	29	23			3, 5
34 ft.	28	43	36	32		3, 5, 7
50 ft.	44	65	57	52	47	3, 6, 8, 10

Attaching the rope to the guy ring



Using the cleat tensioner



Installing locking clip after all guy ropes have been tensioned

